

De-Winterizing your Airstream

You are planning your first trip of the spring, so how do you make sure your Airstream is ready?

The process will vary somewhat depending on how you went about getting it ready for winter. You are going to want to check more than just the plumbing system. Here are some things to consider:

1. If you have removed the batteries you will want to make sure they have been charged and reinstalled.
2. Plug your Airstream into 110 volt so you will be able to power up the system to operate lights, control panel and appliances etc.
 - Check power cord and ends
3. Get plumbing system ready - The plan is to run fresh water through all pipes, faucets, water heater and into the gray & black tanks.
 - Make sure all low point drain valves are closed.
 - If your system has a bypass set up for the water heater, it should have been put in the bypass mode to winterize; set the valve positions to the normal operating mode.