

Airstream Sub-Flooring

The question still comes up as to what type of sub-flooring is used on Airstream trailers, they want to know if OSB (oriented strand board) is still being used.

Airstream currently is using 5/8" tongue and groove Exposure 1 plywood on all current US model trailers.



Exposure 1 plywood is made using a fully waterproof bond and good for use in high moisture conditions. Airstream has been using plywood on all but two models for many years and the switch was made to plywood on the two remaining models (16 and 22 ft.) using OSB in May of 2007.