

Rivet Replacement

I noticed that a rivet on the outside of my Airstream trailer fell out. Your store has different rivet packets for sale. Can you tell me what rivet size or number or type I need to fix the missing rivet; also what tools will I need You will need an Olympic rivet (Airstream part number 682616-01, Olympic rivet with washer) www.airstream.com click on store tab. I recommend buying the ones with the rubber washer so you won't need to buy a tube of caulking. You will need a Pop Gun with the various nose sizes. A drill with a no. 21 drill bit. Once the rivet has been installed and the stem nipped off, you can use a Dremel tool with a polishing attachment to polish the rivet head to match the other rivets.