

# **Air Conditioning System**

## **MAINTENANCE**

1. The primary maintenance requirements for an A-C is to keep the inside filters and the outside coils clean. You can use a vacuum and/or compressed air.
2. Insure that all electrical connections are tight and not corroded.
3. If you have A-C water drain tubes inside your walls you should reverse blow these out every year after your first heavy use day. This will get the dust and dirt out of the drain pan nipples and insure that you will not be rained on inside your coach.