


# Trouble Shooting Tips for the Deluxe Hi-Power Barker 3000 Hitch Jack

## Hinge Adjustment Tips

The adjustment of Euro cabinet hinges maybe puzzling when you first look at the cabinet hinge but in reality they are easy to adjust once you know which screw does what.

*The three center screws do not tighten the hinge!*





### Trouble shooting

No power:

- Kill switch/battery disconnect not turned on
- Batteries have no power
- No 12v power from tow vehicle
- Inline fuse blown at base of jack post
- Poor Ground:

(When switch is activated on jack - jack operates only partially up or down or jack runs intermittently)

Possible Cause:

1. Jack head loose not making contact with post
2. Jack base not grounded - should have star washer on bolts

that holds jack to coupler

- Jack head defective



*130 Amp Fuse for Power Jack*