

Some reminders for your generator on Class A or B Motorhomes

The generator oil and filter should be changed at recommended intervals (Consult owner's manual for specific recommendations).

A good rule of thumb is around 150 hours of use.

It is also recommended that the generator be run once a month for 30 minutes with a constant load to keep the generator lubricated; this will also help remove moisture from the generating unit.

If you have a gasoline generator you may want to consider adding an additive called Sta-Bil to the gas to help keep the gas fresh if not used on a frequent basis.

If your generator is located under the motorhome inspect for dirt build up on or around the generator, your generator needs a good air flow to function properly.

Check for damage to generator or look for any signs oil or fuel leaks.

Do you know where your generator transfer switch is located? The contacts can stick in the transfer switch box and not let your unit switch between shore power and generator. (Don't get into this box with power on.) Be aware that your generator may have resets (breakers) located on the generator, this should be one of the first places to look if you are not getting power from your generator.