

Tires By The Numbers

5 Tire Care Tips

To help make regular tire maintenance and service simple, here are five key areas needing your attention:

1. Regularly inspect your tires for damage.
2. Keep your tires properly inflated in order to maximize performance. (Cold inflation pressure readings should be taken daily while traveling and monthly if in storage).
3. Make sure your Gross Vehicle Weight does not exceed the Gross Vehicle Weight Rating. (Have your RV weighed).
4. Make sure the load on your tires is evenly distributed.
5. Have your tire and wheel maintenance performed regularly. (Wash tires with soap and water, clean and wax rims, torque lug nuts and inspect valve stem caps.)

