

Wheel Bearing Greased

Question: The trailer has about 8,000 miles: When do I need to have the wheel bearings greased?

Answer: Airstream recommends that the wheel bearings should be done after 10,000 miles or at least every 6 months. Trailer Life recommends 10,000 miles or at least once per year. If you do several trips during the winter months in snow areas, I would do the bearings more frequently to get the road salts and sand out of them.