

## Main Door Hinge Pin

**Question:** Lower Hinge Pin on Main Door: The lower hinge pin on the door to the unit slowly rides up above the hinge as you operate the door over time. I have knocked it back several times with a punch when it gets to a 1/4" or so. Is there a trick to securing this naughty pin for once and for all?

**Answer:** You need to slightly expand the pin top with a small punch. With the pin properly seated, put a small sharp end punch (about 1/16 of an inch in diameter) into the center of the pin and give it a few good whacks. This should expand the head and lock the pin in place.